C30, 2008, MMT6

Maintenance service

Program point:	year:	1	2	3	4	5	6	7	8	9	10
	km x 1000:	20	40	60	80	100	120	140	160	180	200
	miles x 1000:	12.5	25	37.5	50	62.5	75	87.5	100	112.5	125
Parking brake -check and adjust		x	x	x	x	x	x	x	x	x	x
External lighting -check the function		x	x	x	x	x	x	x	x	x	x
Horn - check the signal		x	x	x	x	x	x	x	x	x	x
Headlamp/fog lamp -check and align headlamps		x	x	x	x	x	x	x	x	x	x
Washer / wipers for windshields and headlamps -check the function and for signs of wear		x	x	x	x	x	x	x	x	x	x
Seat belts -check the function and for signs of wear		x	x	x	x	x	x	x	x	x	x
Program point:	**year:**	**1**	**2**	**3**	**4**	**5**	**6**	**7**	**8**	**9**	**10**
	km x 1000:	**20**	**40**	**60**	**80**	**100**	**120**	**140**	**160**	**180**	**200**
	miles x 1000:	**12.5**	**25**	**37.5**	**50**	**62.5**	**75**	**87.5**	**100**	**112.5**	**125**
Raise the vehicle											
Engine, transmission, transmission -check for leaks	In event of leakage from the transmission, check the oil level.	x	x	x	x	x	x	x	x	x	x
Engine oil, oil filter - drain the oil. Replace the oil filter		x	x	x	x	x	x	x	x	x	x
Wheels and tires											

(excluding spare wheel) - check for damage, wear, tire pressure		x	x	x	x	x	x	x	x	x	x
Program point:	**year:**	**1**	**2**	**3**	**4**	**5**	**6**	**7**	**8**	**9**	**10**
	km x 1000:	**20**	**40**	**60**	**80**	**100**	**120**	**140**	**160**	**180**	**200**
	miles x 1000:	**12.5**	**25**	**37.5**	**50**	**62.5**	**75**	**87.5**	**100**	**112.5**	**125**
Drive shafts -check the play -check rubber bellows				x			x			x	
Brake pads, brake discs -check	Brake pads, front, check Brake pads, rear, check	x	x	x	x	x	x	x	x	x	x
Brake lines, fuel lines -check for leakage and damage				x			x			x	
Program point:	**year:**	**1**	**2**	**3**	**4**	**5**	**6**	**7**	**8**	**9**	**10**
	km x 1000:	**20**	**40**	**60**	**80**	**100**	**120**	**140**	**160**	**180**	**200**
	miles x 1000:	**12.5**	**25**	**37.5**	**50**	**62.5**	**75**	**87.5**	**100**	**112.5**	**125**
Front suspension, steering system -check for signs of wear				x			x			x	
Rear wheel suspension -check for signs of wear				x			x			x	
Diesel particle filter -replace - resetting the kilometre counter particle filter (ECM)	**Change only according to km/miles interval** Particle filter diesel						x				
Topping up the additive engines with diesel particle filter - top up the additive - resetting the tank level counter (ADM)	**Perform only according to km/miles interval** Tank additive, filling			x			x			x	
Lower the vehicle											
	Change										

Air cleaner (ACL), engine -replace	**only according to km/miles interval** Clean the air cleaner (ACL) housing.			x			x			x	
Fuel filter -replace	**Change only according to km/miles interval**			x			x			x	
-drain off the condensation		x	x		x	x		x	x		x
Fuel filter In markets with contaminated fuel: -replace	**10 000 - 20 000 km** interval										
Program point:	**year:**	**1**	**2**	**3**	**4**	**5**	**6**	**7**	**8**	**9**	**10**
	km x 1000:	**20**	**40**	**60**	**80**	**100**	**120**	**140**	**160**	**180**	**200**
	miles x 1000:	**12.5**	**25**	**37.5**	**50**	**62.5**	**75**	**87.5**	**100**	**112.5**	**125**
Fluid levels - engine compartment -check and adjust brake fluid, clutch fluid, washer fluid, coolant		x	x	x	x	x	x	x	x	x	x
Engine coolant -check and adjust the anti-freeze rating and anti-corrosion agent		x	x	x	x	x	x	x	x	x	x
Battery -check terminal shoes, electrolyte level, mounting				x			x			x	
Vehicles with temporary tire sealing kit -check the container with sealer fluid, replace every fourth year, see decal.											
Accessory Drive Belt											

-replace the belt according to the service program or: - replace the belt at a **maximum 10 year** interval											
Program point:	**year:**	**1**	**2**	**3**	**4**	**5**	**6**	**7**	**8**	**9**	**10**
	km x 1000:	**20**	**40**	**60**	**80**	**100**	**120**	**140**	**160**	**180**	**200**
	miles x 1000:	**12.5**	**25**	**37.5**	**50**	**62.5**	**75**	**87.5**	**100**	**112.5**	**125**
Timing belt / belt tensioner/ idler pulley -replace according to the service program or: - replace at a **maximum 10 year** interval											
Air cleaner (ACL) passenger compartment -replace		x	x	x	x	x	x	x	x	x	x
Roof system C70 - check - lubrication	See: Service program/838 Convertible roof/Service roof system	x	x	x	x	x	x	x	x	x	x
Brake fluid -replace	Recommend that a customer with normal mileage has the fluid replaced every other year.		x		x		x		x		x
	The fluid must be replaced every year if the car is used for mountain driving or is mainly used in humid climates.	x	x	x	x	x	x	x	x	x	x
SRI - set the	Resetting the service										

service reminder indicator (SRI) to zero	reminder indicator (SRI)	x	x	x	x	x	x	x	x	x	x

Program point:	**year:**	**11**	**12**	**13**	**14**	**15**	**16**	**17**	**18**	**19**	**20**
	km x 1000:	**220**	**240**	**260**	**280**	**300**	**320**	**340**	**360**	**380**	**400**
	miles x 1000:	**137.5**	**150**	**162.5**	**175**	**187.5**	**200**	**212.5**	**225**	**237.5**	**250**
Parking brake -check and adjust		x	x	x	x	x	x	x	x	x	x
External lighting -check the function		x	x	x	x	x	x	x	x	x	x
Horn - check the signal		x	x	x	x	x	x	x	x	x	x
Headlamp/fog lamp -check and align headlamps		x	x	x	x	x	x	x	x	x	x
Washer / wipers for windshields and headlamps -check the function and for signs of wear		x	x	x	x	x	x	x	x	x	x
Seat belts -check the function and for signs of wear		x	x	x	x	x	x	x	x	x	x
Program point:	**year:**	**11**	**12**	**13**	**14**	**15**	**16**	**17**	**18**	**19**	**20**
	km x 1000:	**220**	**240**	**260**	**280**	**300**	**320**	**340**	**360**	**380**	**400**
	miles x 1000:	**137.5**	**150**	**162.5**	**175**	**187.5**	**200**	**212.5**	**225**	**237.5**	**250**
Raise the vehicle											
Engine, transmission, transmission -check for leaks	In event of leakage from the transmission, check the oil level.	x	x	x	x	x	x	x	x	x	x
Engine oil, oil filter -drain the oil and replace the oil filter		x	x	x	x	x	x	x	x	x	x
Wheels and tires (excluding spare wheel) - check for damage, wear, tire pressure		x	x	x	x	x	x	x	x	x	x

Program point:	**year:**	**11**	**12**	**13**	**14**	**15**	**16**	**17**	**18**	**19**	**20**
	km x 1000:	**220**	**240**	**260**	**280**	**300**	**320**	**340**	**360**	**380**	**400**
	miles x 1000:	**137.5**	**150**	**162.5**	**175**	**187.5**	**200**	**212.5**	**225**	**237.5**	**250**
Drive shafts -check the play -check rubber bellows			x			x			x		
Brake pads, brake discs - check	Brake pads, front, check Brake pads, rear, check	x	x	x	x	x	x	x	x	x	x
Brake lines, fuel lines -check for leakage and damage			x			x			x		
Program point:	**year:**	**11**	**12**	**13**	**14**	**15**	**16**	**17**	**18**	**19**	**20**
	km x 1000:	**220**	**240**	**260**	**280**	**300**	**320**	**340**	**360**	**380**	**400**
	miles x 1000:	**137.5**	**150**	**162.5**	**175**	**187.5**	**200**	**212.5**	**225**	**237.5**	**250**
Front suspension, control system -check for signs of wear			x			x			x		
Rear wheel suspension -check for signs of wear			x			x			x		
Diesel particle filter -replace - resetting the kilometre counter particle filter (ECM)	**Change only according to km/miles interval** Particle filter diesel		x						x		
Topping up the additive engines with diesel particle filter - top up the additive - resetting the tank level gauge (ADM)	**Perform only according to km/miles interval** Tank additive, filling		x			x			x		
Lower the vehicle											
Air cleaner (ACL), engine -replace	**Change only according to km/miles interval** Clean the air cleaner (ACL) housing.		x			x			x		
	Change only										

Fuel filter -replace	**according to km/miles interval**		x			x			x		
-drain off the condensation		x		x	x		x	x		x	x
Fuel filter In markets with contaminated fuel: -replace	**10 000 - 20 000 km** interval										
Program point:	**year:**	**11**	**12**	**13**	**14**	**15**	**16**	**17**	**18**	**19**	**20**
	km x 1000:	**220**	**240**	**260**	**280**	**300**	**320**	**340**	**360**	**380**	**400**
	miles x 1000:	**137.5**	**150**	**162.5**	**175**	**187.5**	**200**	**212.5**	**225**	**237.5**	**250**
Fluid levels - engine compartment -check and adjust brake fluid, clutch fluid, washer fluid, coolant		x	x	x	x	x	x	x	x	x	x
Engine coolant - check /adjust the anti-freeze/corrosion protection rating		x	x	x	x	x	x	x	x	x	x
Battery - check terminal shoes, electrolyte level, mounting			x			x			x		
Vehicles with temporary tire sealing kit - check the container with sealer fluid, replace every fourth year, see decal.											
Accessory Drive Belt -replace the belt according to the service program or: - replace the belt at a **maximum 10 year** interval			x								
Program point:	**year:**	**11**	**12**	**13**	**14**	**15**	**16**	**17**	**18**	**19**	**20**
	km x 1000:	**220**	**240**	**260**	**280**	**300**	**320**	**340**	**360**	**380**	**400**
	miles x 1000:	**137.5**	**150**	**162.5**	**175**	**187.5**	**200**	**212.5**	**225**	**237.5**	**250**
Timing belt / belt											

tensioner/ idler pulley -replace according to the service program or: - replace at a **maximum 10 year** interval			x								
Air cleaner (ACL) passenger compartment -replace		x	x	x	x	x	x	x	x	x	x
Roof system C70 - check - lubrication	See: Service program/838 Convertible roof/Service roof system	x	x	x	x	x	x	x	x	x	x
Brake fluid -replace	Recommend that a customer with normal mileage has the fluid replaced every other year.		x		x		x		x		x
	The fluid must be replaced every year if the car is used for mountain driving or is mainly used in humid climates.	x	x	x	x	x	x	x	x	x	x
SRI - set the service reminder indicator (SRI) to zero	Resetting the service reminder indicator (SRI)	x	x	x	x	x	x	x	x	x	x